




MAX 17

CLEANING YOUR FANS

STEP 1

Remove the back cover. Screw holes are highlighted in RED:




STEP 2


After the back panel is removed inspect for any signs of dust or debris, now is the time to clean it up.




STEP 3

Remove the 3 screws and the plug holding in the fan. Also, cut one or both sections of tape holding down the fan to either pull back the fan or pull out the fan. We will also be removing the fan cable, you will need to pull out the plug by pulling it out towards the fan (see below images)







STEP 4

Clean out the fans, you can pick out the dust and then spray out the fans the rest of the way with compressed air or use a toothbrush.



To finalize the repair you can do reverse of the removal.

Please let us know if you have any questions or any improvements to add to this guide.

