



*Double tapping the left corner will turn the touchpad on or off.




- 11 Vents
- 12 Speakers

- 01 Camera Status LED
- 02 Camera
- 03 Microphone
- 04 LCD screen
- 05 Caps Lock LED indicator
- 06 Mode Switch & LED indicator
- 07 Power Button
- 08 Keyboard
- 09 Touchpad LED indicator/Touchpad switch
- 10 Touchpad



- 13 Card Reader
- 14 USB Ports
- 15 Vents
- 16 Kensington® Lock Port
- 17 USB Port
- 18 Mic In Jack
- 19 Audio Out Jack



- 20 LPP G2 Liquid Port
- 21 USB Type C Port
- 22 HDMI Port
- 23 Network Jack
- 24 Power Connector
- 25 Vents

Powering On

Warning: The AC adapter included with your MECH-16 GP was specifically designed and approved for this model. Utilization of an aftermarket AC adapter may damage the laptop or other devices connected to it. If damage is determined to have been caused by an unauthorized power supply, it will not be protected under warranty.

