






★ Tap left corner twice to enable or disable (light) touchpad functionality




11- Vents
12- Speakers

- 1- Camera Status LED
- 2- Webcam & Infrared Sensor For Facial Recognition
- 3- Microphones
- 4- LCD Screen
- 5- Caps Lock Status LED
- 6- Power Mode Switch
- 7- Power Button
- 8- Keyboard
- 9- Touchpad LED Indicator/Touchpad Switch
- 10- Touchpad/Clickpad



- 13- Card Reader
- 14- USB Port
- 15- Vents
- 16- Kensington® Lock Port
- 17- USB Port
- 18- Mic-In Jack
- 19- Audio-Out Jack



- 20- Vents
- 21- LPP Connector Heads
- 22- USB Type-C Port
- 23- HDMI port
- 24- Network Jack
- 25- Power Connector
- 26- RGB Light Bar

Get Started

*Please Note: The AC adapter included with your PC was specifically designed and approved for your model. Utilization of an after-market adapter may damage either the notebook or other devices connected to it. If damage is determined to have been caused by utilization of an unauthorized power supply, it will not be protected under warranty.

